


Residential Smart PV Solution Quick Guide

(Three-Phase PV+ESS Scenario + Smart Dongle Networking)

Issue: 07
Date: 2024-07-15




1 Networking



- NOTE**
- The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.
 - For details about the solution components, installation, and cable connections, see the corresponding user manuals and quick guides.
 - The cable colors involved in this document are for reference only. Select cables in accordance with local cable specifications.

2 Product Overview



Component	Model	Description
Inverter (master and slave)	SUN2000-(5KTL-12KTL)-M1 SUN2000-(12K-25K)-MB0 series SUN2000-(8KTL-20KTL)-M2 SUN2000-(12KTL-25KTL)-M5 series SUN2000-(5K-12K)-MAP0 series	SUN5000-(8KTL, 12KTL)-MAP0 series SUN5000-(17K, 25K)-MB0 series
Energy storage system (ESS)	LUNA2000-(5-30)-S0 LUNA2000-(7, 14, 21)-S1	<ul style="list-style-type: none"> If there is only one ESS, it must be connected to the master inverter. Each M1/MAP0 can connect to a maximum of two ESSs, and each MB0 can connect to a maximum of four ESSs (each battery terminal can connect to a maximum of two batteries). The LUNA2000-(5-30)-S0 and LUNA2000-(7, 14, 21)-S1 cannot connect to the same inverter in a parallel system. If inverters are cascaded, the LUNA2000-(5-30)-S0 and LUNA2000-(7, 14, 21)-S1 cannot connect to different inverters.
Backup Box	Backup Box-B1	<ul style="list-style-type: none"> AC input voltage range: grid-tied (three-phase) 342-440 V; off-grid (single-phase) 220/230 V If there is only one Backup Box, it must be connected to the master inverter. Only M1 can be connected to the Backup Box-B1.
Smart Power Sensor	DTSU666-H DTSU666-HW YDS60-80 YDS60-C24 DTSU71 DHSU1079-CT	<ul style="list-style-type: none"> The Smart Power Sensor must be connected to the master inverter. It connects to the inverter over RS485 for output power management and power limiting.
Smart Dongle	SDongleB-06 (4G) SDongleA-05 (WLAN-FE)	<ul style="list-style-type: none"> The Smart Dongle must be connected to the master inverter. It connects to the management system and performs power scheduling.
Smart PV Optimizer	SUN2000-450W-P2 SUN2000-600W-P MERC-600W-PA0 MERC-(1300W, 1100W)-P	For details about the optimizer supported by the inverter, see: <ul style="list-style-type: none"> SUN2000 Smart PV Optimizer User Manual MERC-600W-PA0 Smart PV Optimizer User Manual MERC-(1300W, 1100W)-P Smart PV Optimizer User Manual

NOTICE

When MB0 functions as the master inverter and needs to connect to both a power meter and ESS, if more than two ESSs are connected, select one of the following meter models: DTSU666-HW, YDS60-80, YDS60-C24, DTSU71, and DHSU1079-CT. The DTSU666-H is not supported. Ensure that the baud rate for RS485-2 is negotiated to 115200 bit/s. For details about baud rate negotiation, see [Baud Rate Negotiation](#).

Residential Smart PV Solution Quick Guide


(Three-Phase PV+ESS Scenario + Smart Dongle Networking)



3 Cable Connections (Three-Phase Inverter M1 + ESS S0 + Backup Box B1 + Smart Dongle)

DANGER
Before connecting cables, ensure that all switches are OFF. Otherwise, electric shocks may occur.

NOTICE
The wiring sequence of the Backup Box must be consistent with that of the inverter AC terminals.



NOTICE
Connect other cables to slave inverters by referring to the connection method for the master inverter.

NOTICE
Signal cables must be outdoor shielded twisted pair cables.

Cable Type	No.	One End		The Other End	
		Component	Port	Port	Component
DC power cable	1	Master inverter	PV1+ PV1-	Positive terminal Negative terminal	PV strings
	2	Master inverter	BAT+ BAT-	BAT+ BAT-	ESS 1
	3	ESS 1	BAT+ BAT-	BAT+ BAT-	ESS 2
Signal cable	4	Master inverter	COM-13	COM-2(right)	ESS 1
			COM-11	COM-3(right)	
			COM-7	COM-4(right)	
			COM-9	COM-7(right)	
	5	ESS 1	COM-2(left)	COM-2(right)	ESS 2
			COM-3(left)	COM-3(right)	
			COM-4(left)	COM-4(right)	
	6	Slave inverter 1	COM-1	COM-2	Slave inverter 2
			COM-3	COM-4	
4	Master inverter	COM-8	X4-1	Backup Box	
		COM-16	X4-2		
		COM-9	25		
		COM-7	24		
5	ESS 1	COM-2(left)	COM-2(right)	ESS 2	
		COM-3(left)	COM-3(right)		
		COM-7(left)	COM-7(right)		
		COM-8(left)	COM-8(right)		
6	Slave inverter 1	COM-1	COM-2	Slave inverter 2	
		COM-3	COM-4		

Cable Type	No.	One End		The Other End	
		Component	Port	Port	Component
AC power cable	7	Master inverter	AC-L1	X3-1 (L1)	Backup Box
			AC-L2	X3-3 (L2)	
			AC-L3	X3-5 (L3)	
			AC-N	X3-8 (N)	
8	Backup load power distribution box	L	X1-1	Backup Box	
		N	X1-2		
		PE	X1-4		
9	AC power distribution box	L1	X2-1	Backup Box	
		L2	X2-2		
		L3	X2-3		
		N	X2-4		
10	AC power distribution box	L1	3	DTSU666-H	
		L2	6		
		L3	9		
11	AC power distribution box	L1	13	DTSU666-H CT	
		L2	14		
		L3	16		
		L3	17		

Residential Smart PV Solution Quick Guide


(Three-Phase PV+ESS Scenario + Smart Dongle Networking)



3 Cable Connections (Three-Phase Inverter M1 + ESS S1 + Backup Box B1 + Smart Dongle)

⚠ DANGER
Before connecting cables, ensure that all switches are OFF. Otherwise, electric shocks may occur.

NOTICE
The wiring sequence of the Backup Box must be consistent with that of the inverter AC terminals.



NOTICE
Connect other cables to slave inverters by referring to the connection method for the master inverter.

NOTICE
Signal cables must be outdoor shielded twisted pair cables.

Cable Type	No.	One End		The Other End		
		Component	Port	Port	Component	
DC power cable	1	Master inverter	PV1+	Positive terminal	PV strings	
			PV1-	Negative terminal		
	2	Master inverter	BAT+	BAT+	ESS 1	
Signal cable	3	ESS 1	BAT+	BAT+	ESS 2	
	4	Master inverter	COM-13	COM-5	ESS 1	
			COM-11	COM-4		
			COM-7	COM-2		
			COM-9	COM-3		
			COM-8	X4-1		Backup Box
			COM-16	X4-2		
	5	ESS 1	COM-9	25	DTSU666-H	
			COM-7	24		
			COM-7	COM-7		
			COM-8	COM-8		
			COM-9	COM-9		
COM-10			COM-10			
6	Slave inverter 1	COM-1	COM-2	Slave inverter 2		
		COM-3	COM-4			

Cable Type	No.	One End		The Other End	
		Component	Port	Port	Component
AC power cable	7	Master inverter	AC-L1	X3-1 (L1)	Backup Box
			AC-L2	X3-3 (L2)	
			AC-L3	X3-5 (L3)	
			AC-N	X3-8 (N)	
	8	Backup load power distribution box	L	X1-1	Backup Box
			N	X1-2	
	9	AC power distribution box	L1	X2-1	Backup Box
			L2	X2-2	
			L3	X2-3	
			N	X2-4	
			PE	X2-6	
10	AC power distribution box	L1	3	DTSU666-H	
		L2	6		
		L3	9		
11	AC power distribution box	N	10	DTSU666-H CT	
		L1	13		
		L2	16		
		L3	19		

Residential Smart PV Solution Quick Guide

(Three-Phase PV+ESS Scenario + Smart Dongle Networking)



3 Cable Connections (Three-Phase Inverter MB0 + ESS S0 + Smart Dongle)

⚠ DANGER


Before connecting cables, ensure that all switches are OFF. Otherwise, electric shocks may occur.

NOTICE

Signal cables must be outdoor shielded twisted pair cables.

NOTICE

Connect other cables to slave inverters by referring to the connection method for the master inverter.



Cable Type	No.	One End		The Other End	
		Component	Port	Port	Component
DC power cable	1	Master inverter	PV1+	Positive terminal	PV strings
	2	Master inverter	PV1-	Negative terminal	PV strings
	3	ESS 1	BAT+	BAT+	ESS 2
Signal cable	4	ESS 1	COM-2(left)	COM-2(right)	ESS 2
			COM-3(left)	COM-3(right)	
			COM-4(left)	COM-4(right)	
			COM-7(left)	COM-7(right)	
	5	Master inverter	COM-8(left)	COM-8(right)	ESS 1
			COM-9(left)	COM-9(right)	
			COM-9	COM-7(right)	
6	Master inverter	COM-7	COM-4(right)	Slave inverter 1	
7	Slave inverter 1	COM-1	COM-2	Slave inverter 2	
8	Master inverter	COM-3	COM-4		
			COM-7	24	DTSU666-H
			COM-9	25	

Cable Type	No.	One End		The Other End		
		Component	Port	Port	Component	
AC power cable	9	Master inverter	L1	L1	AC power distribution box	
			L2	L2		
			L3	L3		
			N	N		
	10	AC power distribution box	L1	3	DTSU666-H	
			L2	6		
			L3	9		
	11	AC power distribution box	N	10	DTSU666-H CT	
				L1		13
				L2		16
				L3		17

Residential Smart PV Solution Quick Guide

(Three-Phase PV+ESS Scenario + Smart Dongle Networking)




3 Cable Connections (Three-Phase Inverter MB0 + ESS S1 + Smart Dongle)

DANGER

Before connecting cables, ensure that all switches are OFF. Otherwise, electric shocks may occur.

NOTICE

Signal cables must be outdoor shielded twisted pair cables.



NOTICE
Connect other cables to slave inverters by referring to the connection method for the master inverter.

Cable Type	No.	One End		The Other End	
		Component	Port	Port	Component
DC power cable	1	Master inverter	PV1+	Positive terminal	PV strings
			PV1-	Negative terminal	
	2	Master inverter	BAT+	BAT+	ESS 1
		BAT-	BAT-		
	3	ESS 1	BAT+	BAT+	ESS 2
			BAT-	BAT-	
Signal cable	4	ESS 1	COM-7	COM-7	ESS 2
			COM-8	COM-8	
			COM-9	COM-9	
			COM-10	COM-10	
	5	Master inverter	COM-11	COM-2	ESS 1
			COM-12	COM-3	
			COM-13	COM-4	
			COM-11	COM-5	
6	Master inverter	COM-1	COM-2	Slave inverter 1	
7	Slave inverter 1	COM-1	COM-2	Slave inverter 2	
8	Master inverter	COM-3	COM-4	DTSU666-H	
		COM-7	24		
		COM-9	25		


Cable Type	No.	One End		The Other End	
		Component	Port	Port	Component
AC power cable	9	Master inverter	L1	L1	AC power distribution box
			L2	L2	
			L3	L3	
			N	N	
			PE	PE	
10	AC power distribution box	L1	3	DTSU666-H	
		L2	6		
		L3	9		
		N	10		
11	AC power distribution box		L1	13	DTSU666-H CT
			L2	14	
			L2	16	
			L2	17	
			L3	19	
		L3	21		

Residential Smart PV Solution Quick Guide

(Three-Phase PV+ESS Scenario + Smart Dongle Networking)



3 Cable Connections (Three-Phase Inverter MAP0 + ESS S0 + Smart Dongle)



⚠ DANGER
Before connecting cables, ensure that all switches are OFF. Otherwise, electric shocks may occur.

NOTICE
Connect other cables to slave inverters by referring to the connection method for the master inverter.

NOTICE
Signal cables must be outdoor shielded twisted pair cables.

PE	1	10	PE
Enable-	2	9	CANH
Enable+	3	8	CANL
485A	4	7	485B
485A	5	6	485B

Cable Type	No.	One End		The Other End	
		Component	Port	Port	Component
DC power cable	1	Master inverter	PV1+	Positive terminal	PV strings
		Master inverter	PV1-	Negative terminal	
	2	Master inverter	BAT+	BAT+	ESS 1
	3	ESS 1	BAT-	BAT-	ESS 2
			BAT+	BAT+	
Signal cable	4	ESS 1	COM-2 (left)	COM-2 (right)	ESS 2
			COM-3 (left)	COM-3 (right)	
			COM-4 (left)	COM-4 (right)	
			COM-7 (left)	COM-7 (right)	
	5	Inverter 1	COM: RJ45 network port	COM-2	ESS 1
				COM-3	
	6	Master inverter	COM-1	COM-1	Slave inverter 1
			COM-3	COM-3	
	7	Slave inverter 1	COM-1	COM-1	Slave inverter 2
COM-3			COM-3		
8	Master inverter	COM-7	24	DTSU666-H	
		COM-9	25		

Cable Type	No.	One End		The Other End	
		Component	Port	Port	Component
AC power cable	9	Master inverter	L1	L1	AC power distribution box
			L2	L2	
			L3	L3	
10	AC power distribution box	DTSU666-H	N	N	
			L1	3	
			L2	6	
			L3	9	
11	AC power distribution box	DTSU666-H CT	N	10	
			L1	13	
				14	
			L2	16	
			L3	17	

Residential Smart PV Solution Quick Guide

(Three-Phase PV+ESS Scenario + Smart Dongle Networking)



3 Cable Connections (Three-Phase Inverter MAP0 + ESS S1 + Smart Dongle)

DANGER


Before connecting cables, ensure that all switches are OFF. Otherwise, electric shocks may occur.

NOTICE

Connect other cables to slave inverters by referring to the connection method for the master inverter.

NOTICE

Signal cables must be outdoor shielded twisted pair cables.



Cable Type	No.	One End		The Other End	
		Component	Port	Port	Component
DC power cable	1	Master inverter	PV1+	Positive terminal	PV strings
			PV1-	Negative terminal	
	2	Master inverter	BAT+	BAT+	ESS 1
Signal cable	3	ESS 1	BAT+	BAT+	ESS 2
			BAT-	BAT-	
			COM-7	COM-7	
			COM-8	COM-8	
			COM-9	COM-9	
	4	ESS 1	COM-10	COM-10	ESS 2
			COM-11	COM-11	
			COM-12	COM-12	
			COM-13	COM-13	
	5	Inverter 1	COM: RJ45 network port	COM-3	ESS 1
	6	Master inverter	COM-1	COM-1	Slave inverter 1
7	Slave inverter 1	COM-1	COM-1	Slave inverter 2	
8	Master inverter	COM-11	24	DTSU666-H	
		COM-13	25		

Cable Type	No.	One End		The Other End	
		Component	Port	Port	Component
AC power cable	9	Master inverter	L1	L1	AC power distribution box
			L2	L2	
			L3	L3	
			N	N	
			PE	PE	
	10	AC power distribution box	L1	3	DTSU666-H
			L2	6	
			L3	9	
	11	AC power distribution box	DTSU666-H CT	L1	13
				L1	14
				L2	16
L2				17	
L3				19	

Residential Smart PV Solution Quick Guide

(Three-Phase PV+ESS Scenario + Smart Dongle Networking)



4 System Commissioning

App-based Deployment Procedure

- Download and install the FusionSolar app
- Sign up as an installer (optional, required for initial registration)
- Enter the setup wizard
- Check the device status

Downloading and Installing the FusionSolar App

- Search for FusionSolar in the app store to download the app.
- Scan the QR code below to download the app.




FusionSolar

Installer Registration

Initial registration


Create the first installer account, and generate a domain named after the company.




Or

Non-initial registration

If the company requires multiple installer accounts, log in to the FusionSolar app and tap **Add user** to create another installer account.



Setup Wizard (Connecting to the Inverter WLAN for Commissioning)



Residential Smart PV Solution Quick Guide (Three-Phase PV+ESS Scenario + Smart Dongle Networking)



Set the ESS parameters.

Set the ESS installation environment and working mode.

Note: In a non-ESS scenario, the step of **Energy storage control** is not involved.

You can tap to obtain the detailed working mode information.

Set the communication networking.

WLAN communication

I have been authorized by the user to connect to the management system. Monitor the PV plant through the management system.

Setting management system parameters
Domain name: intl.fusionsolar.huawei.com

Setting parameters for the inverter to connect to the router
WLAN: [Selected]
Password: [Entered]

Select the desired router and enter the router password.

Or

4G communication

I have been authorized by the user to connect to the management system. Monitor the PV plant through the management system.

Setting management system parameters
Domain name: intl.fusionsolar.huawei.com

Device parameter settings
APN mode: Automatic
Network mode: 4G/3G/2G automatic selection

By default, APN mode is set to **Automatic**. If you cannot access the Internet in **Automatic** mode, set it to **Manual**. In this case, set the parameters related to the SIM card with the information obtained from the carrier.

Or

FE communication

I have been authorized by the user to connect to the management system. Monitor the PV plant through the management system.

Setting management system parameters
Domain name: intl.fusionsolar.huawei.com

Setting parameters for the inverter to connect to the router
DHCP: [Enabled]

If the Ethernet parameter is displayed, the network cable is not connected. Reconnect the network cable.

Ethernet:

Add a plant.

Create plant

Add plant

Connect to existing plant

Add plant

Basic info

Total string capacity (kWp): [Entered]

Added devices: XXXXXXXXXXXX

Device type: XXXXX

Device model: XXXXX

Connected devices

Submit

Create an owner account.

Plants Statistics

Setup wizard | Add user

1 All | 1 Normal | 0 Faulty | 0 Offline

Enter a plant name.

My PV Plant

China mainland xxx

0.00kWh | 0.00kWh | 100.00kWh

Add user

*Service provider

*Role

*Plant Association

*Username

Avatar

Country/Region code: +86

Mobile number

*Email

I have obtained the owner's authorization.

Save

Checking the Plant Status

Plants Statistics

My PV Plant

China mainland xxx

0.00kWh | 0.00kWh | 100.00kWh

My PV Plant

Weather: [Icon]

Plant details

PV: 30.00 kW

Battery: 20.00 kW

Grid: 20.00 kW

Load: 20.00 kW

0.00 kWh Yield today | 2.36 kWh Revenue today

5.10 kWh Yield this month | 5.10 kWh Yield this year | 5.10 kWh Total yield



Residential Smart PV Solution Quick Guide

(Three-Phase PV+ESS Scenario + Smart Dongle Networking)





5 Off-Grid/Grid-tied Control Parameters

Enabling Off-Grid Mode



Setting Grid-tied Point Control



Residential Smart PV Solution Quick Guide


(Three-Phase PV+ESS Scenario + Smart Dongle Networking)



6 Physical Layout of Smart PV Optimizers


Attaching SN Labels

Remove the SN labels from optimizers and attach them to the physical layout template based on the actual positions of the optimizers in the plant.




Taking a Photo of the Physical Layout Template

Ensure that the four positioning points on the template are within the frame.




Generating a Physical Layout on the App

Enter the Layout screen.



Generating a Physical Layout on the App Automatically

Upload the template and generate a layout.




Residential Smart PV Solution Quick Guide

(Three-Phase PV+ESS Scenario + Smart Dongle Networking)




Creating a Physical Layout on the App Manually

Edit the physical layout and specify the quantity of inverters and PV modules as required.



Bind the inverter or optimizer SN.



Adjust the physical layout.

